



CREATE YOUR OWN / OUTDOOR GUIDE

OUTDOOR SIGNS

IP67 WATERPROOF RATING + SETUP & CARE

TAKE YOUR NEON OUTSIDE.

Choose the outdoor build for shopfronts, patios, gardens and signs exposed to rain. Outdoor components protect your sign while keeping the same design and neon glow.

IP67

OUTDOOR NEON FLEX

6 / DUST-TIGHT

Protection against the entry of dust.

7 / WATER PROTECTION

Protected against temporary immersion in water under defined test conditions.

The IP67 rating applies to the neon flex. Plugs, cable connections and accessories need their own suitable protection. IP67 does not mean the whole setup can be submerged.

YOUR OUTDOOR BUILD

OUTDOOR NEON FLEX

IP67-rated LED neon flex for outdoor display.

WATERPROOF DIMMER

Adjust the brightness using your supplied remote.

OUTDOOR POWER SUPPLY

Matched to your sign and installed in a protected position.

INSTALLATION & CARE

01 MOUNT SECURELY

Use fixings suited to the mounting surface, sign weight and wind exposure. Keep cables supported and clear of walkways.

02 PROTECT YOUR POWER

Keep the mains plug and cable joins dry. Position the supply and dimmer as instructed on their labels. Keep the handheld remote dry.

03 KEEP SEALS INTACT

Use the supplied outdoor components. Keep connectors closed and seals intact. Do not cut tubing or alter sealed cable ends.

04 CLEAN GENTLY

Switch power off before cleaning. Wipe with a soft, lightly damp cloth. Avoid hoses, pressure washers and immersion.

PLAN YOUR INSTALLATION

Use a licensed electrician for fixed wiring and outdoor power connections. Send us a photo of your location if you need help choosing the right outdoor setup.

YOUR COLOUR. YOUR DESIGN. YOUR NEON.

sales@theneonfactory.com.au